

Exactly the **lighting experience** you intended

Philips StagePainter D60 2000 - Takes LED to a new level of performance

Exactly the lighting experience you intended, time after time after time. The lighting experiences you create have the power to captivate audiences and turn a performance into something magical. To bring out the best in your talents, you need fixtures that maximise your scene-setting capabilities and recreate them perfectly. Now you can do just that with StagePainter D60 2000 - a system that's so flexible and controllable, it can paint exactly the scene wyou imagined with brilliant LED light.

StagePainter puts creative freedom and lighting control at your fingertips with integrated colour mixing and an easy to use interface. Bring your ideas to life in an endless palette of fast, tunable, white or coloured light. Play with colour, intensity, hue and saturation to light breathtaking moods and dynamic effects. Then recreate them flawlessly, fixture after fixture, night after night.

Features	Benefits
Smart system (LED + Driver)	Easy to design-in and easy and intuitive interface
Internal colour feedback mechanism	Internal colour feedback mechanism
Integrated colour mixing	Integrated colour mixing
High colour purity	Nice saturated colours can be displayed
Dimming to 0 without visible steps	Smooth dimming
Adjustable Tc: 2700-6500K	Allows perfect control of colour temperature and light output level, ideal for TV studio
Improved transition time	Fast strobing possible

Light Technical Characteristics

Type	Philips StagePainter D60 2000		
Light Output (lm)	W: 2000 R: 340 G: 475 B: 115		
Dimming (%)	100-0		
Colour Temperature (K)	2700-6500		
Colour Rendering index	>90		
RGB gamut	R: x= 0.670	G: x= 0.210	B: x= 0.150 y= 0.080
Colour consistency initial / at 10 k hrs (SDCM)	5/6		
Lumen mainenance (W)	70% @ 50.000 hrs		
Power (W)	<50		
Efficacy LED module + driver (lm/W)	35-40		
Input Voltage (V)	120-277		
Input Frequency (Hz)	50-60		
Control Interface	DMX/RDM		
TC max (ºC)	65		
Burning position	Universal		

Design-in overview

Company	LUMISIA
Model name	LUMI Painter Max - LUMI Painter - LUMI Painter Mini
Philips lighting system	StagePainter D60 2000

For a LED light experience like no other, it has to be StagePainter from Philips. To find out more about visit www.philips.com/lighting/entertainment

