# SmartBalance – combining performance with smart design

Advanced, elegant and energy efficient



## PHILIPS



### Getting the balance right

Maybe you're looking to specify a luminaire for office lighting and you're interested in reducing the energy or overall operational costs on your project. Perhaps your agenda is to find a more elegant lighting solution that not only meets the required lighting standards but looks good too. Or you need a lighting solution that blends in rather than stands out, to fit with the design aesthetics of your building. Meet SmartBalance, the new flexible and energy efficient luminaire family from Philips.

4/5	Performa
6/7	Beauty an
8/9	Design pl
10/11	SmartBala
12/13	SmartBala
14/15	ActiLume
16/19	Case stuc
20/23	Lighting d
24/27	Case stuc
28	Ease of in
29/30	Specificat
31	Choice sh

- ance with clear value
- and flexibility
- olus performance
- lance surface mounted and suspended optics and features
- alance free floor standing features and benefits
- e Wireless
- ıdy: Planteams.ch AG, Kaegiswil, Switzerland
- design
- udy:Tomra, Brunn am Gebirge, Austria
- nstallation
- ition
- sheet and ordering codes

### Performance with clear value

Whatever your priorities, your goals can now be achieved by using one elegant LED lighting solution that delivers exceptional performance (up to 113 lumens per watt system efficacy with SmartBalance free floor standing) at a reasonable cost. SmartBalance has been designed as a better alternative to traditional T5 and PL-L lighting, whilst offering next generation style and adaptability. Reliable and sustainable, its long lifetime LED technology reduces energy use, also helping to reduce carbon impact, whilst simultaneously enhancing the appeal of your office space. When using controls for presence detection and daylight harvesting, you can easily save an additional 50% on the rated energy consumption level.



### Beauty and flexibility

Stand out or blend in? As a suspended luminaire, SmartBalance's soft, pleasing curves and award-winning minimal design can add appeal to any ceiling. As a surface mounted luminaire, it's as unobtrusive as you need it to be, preventing clutter on the ceiling – fitting seamlessly with your interior architecture concept. And as a free floor standing luminaire it lights up two desks with one luminaire, while blending into the environment thanks to its compact design.

So if you've been waiting for a genuine alternative to T5 and PL-L, we're happy to announce that it's here. Energy efficient, elegant and excellent value for money office lighting has finally arrived. Its name is SmartBalance.



The design perspective

Lilian Marijnissen Senior Design Consultant, Philips Lighting "The design challenge for us with SmartBalance was to bring good value to a dedicated LED office luminaire, whilst achieving good lighting performance and creating something unobtrusive in the office space. The luminaire has a softened geometry, where the volume is optimized around the LED technology, reducing it to its essentials to meet our aim of 'celebrating light'. High standards were set for detailing, finishing and production within challenging cost targets – our ultimate goal being to set a new standard for LED office luminaires."






T8 (TLD) X-tendolight	T5 SmartForm	>SmartBalance	
			Desig
			Our goal with S to create an eff range of office is a contempor with clean desig surface mounte
			Total cost of owner
			Conventional
			SmartBalance

8


## gn plus performance

SmartBalance was to give you the best of both worlds – ffective and flexible lighting solution, suitable for a wide e applications, without compromising on design. The result rary luminaire that offers excellent lighting performance ign, attractive profiles and detailing – whether suspended, red or free floor standing.



#### rship at 50,000 hrs

### SmartBalance surface mounted and suspended optics and features



#### Advanced optics

SmartBalance uses state-of-the-art optics technology. The light generated by the LED boards is guided through a dedicated lens and is internally reflected by a high reflective housing. In order to ensure the right office-compliant beam, the light passes through a Micro Lens Optic (MLO) before entering the application space, ensuring the correct spread of light.


#### OLC micro-lens optic made of clear acrylic (ACC-MLO):

The most efficient solution offering limited brightness (UGR:  $19/L65 < 2,200 \text{ cd/m}^2$ )

OLC micro-lens optic made of acrylic (AC-MLO): The most comfortable solution offering low brightness (UGR: 16/L65 < 1,500 cd/m<sup>2</sup>)

#### OLC micro-lens optic made of polycarbonate (PC-MLO):

The most versatile solution, suitable for emergency lighting and those applications requiring GWT850 offering low brightness (UGR: 16/L65 < 1,500 cd/m<sup>2</sup>)



#### Direct and indirect lighting

One of the benefits of using a suspended luminaire is the opportunity to add indirect lighting to create a more spacious room. When using SmartBalance (SP482P) with both direct and indirect lighting, you will be able to create the right light levels needed for visual performance using direct light, but will also greatly enhance the comfort level and look and feel of the space through indirect light from the luminaire, to create brighter ceilings and walls.

#### Smart coupling

If you want to limit the number of power cables feeding the luminaires you can consider using a coupling piece to make a connected line of up to three luminaires.

#### Wireless control

With ActiLume Wireless (ACW-NS), personal control and lighting controls can be installed without the need for additional wiring, offering convenience, flexibility and aesthetic benefits. It is ideal for lighting installations where it is difficult to pull in additional control wires.

#### Emergency lighting

Optionally you can equip SmartBalance with an emergency lighting function (EL1.5-LED). The indication LED is positioned on the front of the gear tray.

#### Suspension set

SMT1: connection with clips to an exposed T-bar ceiling with two steel-wire suspensions SM1: suspension set twin metal tubes SM2: suspension set with ceiling cap and metal tube















## SmartBalance free floor standing features and benefits



#### Stand-alone style

The SmartBalance free floor standing luminaire means you can now have the clean and minimal style of SmartBalance as a stand-alone, plug-and-play solution.

Its compact size offers complete flexibility of placement and the switch panel on the pole allows easy control of the lighting level.

Using the same optical system of independent LED modules for both direct and indirect light as the suspended version, this free floor standing luminaire offers the same comfortable lighting. It also offers maximum energy efficiency through the use of Philips LED technology.



#### Performance explained

The SmartBalance free floor standing LED luminaire offers 2,000 lumen direct lighting and up to 9,800 lumen indirect (total package 11,800 lumen), suitable for lighting two desks with one luminaire.

A version with 2,000 lumen direct lighting and 2,500 lumen indirect is available to use for applications in which the luminaire is used as an additional source of light. The optic is an OLC micro-lens optic made of clear acrylic (ACC-MLO) which ensures excellent glare control with L65 < 2,000 cd/m<sup>2</sup>.

Power consumption of approximately 106W for the 11,800 lumen version and 40W for the 4,500 lumen version ensures sustainable lighting plans can be made with luminaire efficacy up to 113 lm/W.

#### Lighting workspaces

Direct light focuses on illuminating the task area, while indirect light creates the surrounding light level. Light from a single luminaire is enough for two full workplaces. Two lumen packages are available – an 11,800 lumen combined direct and indirect lighting package, plus a useful 4,500 lumen package for additional lighting, where a general lighting installation already exists but does not offer the required amount of light.

#### Intuitive user interface

One of the benefits that LED brings to free floor standing luminaires is the possibility to independently switch and dim the direct and indirect lighting. The switch panel is integrated into the pole of the luminaire and has separate buttons for direct and indirect light (on SW versions). Adjusting the lighting level to your personal preference is simply done with a push of a button.

#### Intelligent controls

The integrated ActiLume system provides huge energy savings and maximum lighting comfort. The system offers both presence detection, turning the luminaire on only when workspaces are in use and daylight harvesting, by measuring the light level on your desk and setting the luminaire to deliver any additional light that is required.


#### Available in black and silver gray on request












### ActiLume Wireless – endless freedom and flexibility

as OccuSwitch DALI.

for presentations or meetings.



inside SmartBalance



Think controllability without the hassle of data cables – because when you add intelligent control to your system by using ActiLume Wireless, you can do it easily without the need for additional cabling. So if you're restricted by the existing infrastructure, don't want to use 5 wire cables, or simply want to connect your system in the easiest way, then ActiLume Wireless is your ideal choice.

<u></u>

It's perfect for applications where adding new wires is either impossible or too expensive. It suits spaces that need to be changed quickly or upgraded with additional functionality. It's also the easiest way of creating a data network with no need for 5 wire cables (230V + data). This creates opportunities to add functionality later without having a huge cost impact – no additional, expensive wiring is needed after a building is constructed. Where there is no restriction on using data cables, you can pair SmartBalance with wired DALI controls, such

In this meeting room set-up you can easily add a presence detector (3) to work together with SmartBalance luminaires equipped with ActiLume wireless control (1). Commissioning can be done through a remote control (2) that normally would act as a user interface for day to day use.

The remote control allows you to change the light level, set scenes and easily recall scene settings


1 ActiLume Wireless controller 2 Wireless Scene Remote



3 OccuSwitch Wireless corner sensor



### Case study



## Energy-saving lighting for a creative environment

#### Project overview:

Customer and project Planteams.ch AG, Kaegiswil, Switzerland

#### Project team

Planteams.ch AG: Hampi Lussi – management L&G Inventron AG: Urs Stöckli, Cornel Waldvogel – project management Philips Lighting: Giancarlo Biasone – lighting consultant

#### Lighting Solution

SmartBalance suspended

#### Key features

- Long lifetime 50,000 hours

#### Our client

Swiss architect practice Planteams.ch AG describes itself as 'a competent advisor and personal guide to the realization of individual real estate ideas throughout central Switzerland'. Their work focuses on the planning and execution of single and multi-family houses and commercial buildings as well as rural residential and farm buildings. They also offer energy consultancy. The firm has a modern office space, with 18 employees in two different locations.

• Attractive, glare-free LED luminaire, suitable for office use • Energy savings of up to 30% compared to conventional TL5 fluorescent lighting

### Case study



SmartBalance suspended





#### The client perspective

Hampi Lussi CEO Planteams.ch AG



#### Our challenge

The office building in Kägswil is built to Minergie standard – the highest energy standard for new buildings in Switzerland. Therefore the brief for the new first floor office lighting was to achieve significant energy and cost savings. At the same time, the lighting was to offer maximum functionality and be fully integrated into the new office concept. Essential for staff was a delicate, unobtrusive design and excellent lighting providing a 'feel-good effect' for all the five individual offices, plus the open-plan office with its integrated conference corner.

#### Our solution

The chosen solution was SmartBalance suspended, with neutral white light (4,000 K) and DALI lighting controls. SmartBalance combines high performance and efficiency with an appealing elegance – its sleek, flat design fits harmoniously and unobtrusively into the different offices and gives every room in the office an ambience of its own. The award-winning suspended version features both direct with indirect light to brighten ceilings, which helps to give the working environment a greater sense of space. SmartBalance offers high quality, uniform and office compliant lighting – achieved by a combination of sophisticated Micro Lens Optics, plus attractive and unobtrusive 'wing' styling.

#### The results

Highly efficient due to its use of LED and innovative optics, SmartBalance achieves a luminous efficacy of up to 96 lumens per watt. This is reflected in reduced energy consumption, which is up to 30% lower than comparable TL5 fluorescent lamps. Further energy savings have been realized by the use of dimmable DALI controls and its long lifetime of 50,000 hours ensures low maintenance costs. As a modern office luminaire, SmartBalance also supports wellbeing and productivity in the workplace. Its comfortable, high-quality light promotes concentration and helps to reduce fatigue. Hampi Lussi, CEO of Planteams.ch is delighted: "We are all enthusiastic about the solution and we very quickly made a decision to equip our second floor offices with this great LED light – soon we will also convert our other spaces."


"Believe me, architects are not easily satisfied. However, we are convinced by the performance, energy efficiency and the really nice design. We now have light all around us in our new office."

### Lighting design

#### Cell office



SmartBalance SM480C 1xLED35S/840 PSD ACC-MLO Measurements in meters



#### Summary

	Туре	# lums	Sys. power	Ē <sub>m</sub> [lux]	$U_{\circ}$	$W/m^2$	$W/m^2/100lux$
SmartBalance LED	SM480C W24L134 1xLED35S/840 PSD ACC-MLO	4	4×40W	514	0.65	8.23	1.60
Fluorescent T5 alternative (typical)	SmartForm TCS460 1xTL5-49W/840 HFP D8	4	4×55W	525	0.67	11.32	2.16

Base values

Ceiling height

Mounting height

Luminaire spacing

Task area height

Maintenance factor

Reflection factors (ceiling/wall/floor)

2.8m

2.8m

0.75m

0.8


2.4 x 1.5m

70%/50%/20%

### Open plan office



#### SmartBalance SP482P 1xLED40S/840 PSD AC-MLO Measurements in meters



	Туре	# lums	Sys. power	Ē <sub>m</sub> [lux]	$U_{\circ}$	$W/m^2$	W / m <sup>2</sup> / 100lux
SmartBalance LED	SP482P W24L134 1xLED40S/840 PSD AC-MLO	18	18x48W	534	0.76	8.33	1.56
Fluorescent T5 alternative (typical)	SmartForm TPS462 2xTL5-28W/840 HFP D8	18	18×62W	530	0.73	10.76	2.03




1.20	Base values	
2.40	Ceiling height	2.8m
	Mounting height	2,4m
	Luminaire spacing	2.4 x 2.4m
	Reflection factors (ceiling/wall/floor)	70%/50%/20%
	Task area height	0.75m
	Maintenance factor	0.8

### Lighting design

#### Meeting room



SmartBalance SP480P 1xLED30S/840 PSD AC-MLO Measurements in meters



#### Summary

	Туре	# lums	Sys. power	$\bar{E}_{m}^{*}$ [lux]	U <sub>°</sub>	$W/m^2$	$W/m^2/100lux$
SmartBalance LED	SP480P W24L134 1xLED30S/840 PSD AC-MLO	12	350W	664	0.741	9.00	1.36
Fluorescent T5 alternative (typical)	SmartForm TPS460 1×TL5-49W HFP z*	12	380W	683	0.711	9.77	1.43

Base values

Ceiling height Mounting height

Luminaire spacing

Task area height

Maintenance factor

2.8m

2.4m

n.a.

0.75m


0.8

Reflection factors (ceiling/wall/floor) 70%/50%/20%

Open plan office with free floor standing



SmartBalance FS484F LED118S/840 PSD-T MLO Measurements in meters



Summary

	Туре	# lums	Sys. power	$\bar{E}_{m}^{*}$ [lux]	U_*	$W/m^2$	W / m <sup>2</sup> / 100lux
SmartBalance LED	SmartBalance FS484F LED118S/840 PSD-T MLO	8	8×106W	736	0.76	8.18	1.53
Fluorescent T5 alternative (typical)	Savio FFS764 3xPL-L55W HFP AC-MLO	8	8×171W	730	0.71	13.19	2.56


22

\* Results on full desk surface



	Base values	
	Ceiling height	2.8m
3.20	Mounting height	2.0m
	Luminaire spacing	3.6 x 3.2m
	Reflection factors (ceiling/wall/floor)	70%/50%/20%
	Task area height	0.75m
	Maintenance factor	0.8

### Case study



### A two-part strategy, right first time

#### Project overview:

Customer and project Tomra, Brunn am Gebirge, Austria

#### Project team

Philips Lighting, Roman Vögler – lighting consultancy

#### Lighting Solution

#### Key features

- Design-oriented LED lighting with high energy efficiency • Warm white light color throughout for a relaxed look
- Long lifetime 50,000 hours

#### Our client


Tomra, Roman Postl – sales manager, Frey Wolfgang – service manager Frötscher × Prader Architects, Helmut Frötscher – architect Next Office, Andreas Horvath – lighting planning

SmartBalance free floor standing, SmartBalance suspended

For over 40 years, Norway-based company Tomra has been the international leader in collecting recyclable packaging for drinks and other goods. Their 'reverse vending machines' now collect around 30 billion drinks containers per annum. ORWAK balers, used to compress waste into secure bales ready for recycling, ensure that clients save approximately 50,000 transport journeys, 700,000 liters of fuel and up to 50% in disposal costs, due to the resulting space saved.



SmartBalance free floor standing, double workplace





SmartBalance free floor standing, single workplace

#### Our challenge

Tomra's subsidiary in Brunn am Gebirge in Austria wanted a modern LED lighting concept for their new 440 m<sup>2</sup> office floor, that includes an integrated demonstration room, meeting rooms, an open plan office and individual offices. Their brief asked for two aspects to be considered in the lighting solution – firstly to focus on ecological considerations, which, as it operates in the environmental sector, is of major importance to the company. Secondly, the solution needed to comply with lighting norms, be decorative and emit a warm white color throughout – the goal being to generate a comfortable atmosphere for clients and staff alike. An additional challenge was to provide the most effective and aesthetically pleasing lighting for the product cylinders in the demonstration room, which are covered in green acoustic felt made from recycled PET bottles.

#### Our solution

Architect Helmut Frötscher in collaboration with Andreas Horvat at Next Office, devized a harmonious and innovative LED lighting solution that combined SmartBalance suspended luminaires with newly developed SmartBalance free floor standing luminaires, to give a 'family' feel. These were installed for the first time in all of the offices, meeting rooms and the sales room. Each energy-efficient and attractive designer luminaire, with its all-round, glare-free optics and outstanding color reproduction, complies with all the requirements and norms needed to illuminate a double workspace. With their combination of direct and indirect light, they also brighten up the ceiling, making rooms seem larger and more spacious. The 3,000K warm white light conveys a cosy overall impression. A control system based on daylight harvesting and human presence detection ensures maximum energy savings.

#### The results

This choice of lighting provided Tomra with an integrated lighting solution. The high level of energy efficiency and the long service life of up to 50,000 operating hours meet the company's ecological standards, as does the daylight and presence-based control system for the SmartBalance standard luminaires. Implementing them at all of the computer workstations contributes to staff wellbeing and motivation throughout the workplace, where the high-quality lighting aids concentration. In the demonstration room, an intelligent mix of lighting accentuates the presentation cylinders visually and reinforces the impression that the technology on display is sophisticated and performs well.

"It's unusual to see all of the requirements being met and a concept being implemented 1:1 as planned. Everyone loves the results."


Helmut Frötscher, Architect


Flexible solution to give light where it is needed

### Ease of installation


We have aimed to make installation as simple as possible. SmartBalance surface mounted and suspended luminaires consist of two parts, a gear tray and a housing that can be easily clicked together, both in surface mounted and suspended installation. As standard we offer some installation features to make your life easier – like a service cord, connectors, freedom of mains input for surface mounted and a clutch device for the suspended version. As an option, in case you need more space to hide the power feed, you can also choose a surface mounted gear tray adapter.


SmartBalance free floor standing comes pre-wired with a cord and a plug. Installation requires the base plate and the luminaire head to be connected to the pole of the luminaire.

















1. Service cord enabling one-man installation – leaving your hands free to connect the

3. Gear tray spring for easy clicking of the housing

5. Suspended installation similar to surface mounted

6. Clutch device, for straightforward tuning of the

7. Surface mounted gear tray adapter – in case you need more space to hide the power feed

4. Surface mounted installation – freedom of

2. LED engine with simple connection

LED engine

to the gear tray

mains wire input

luminaire height



Turne


#### SmartBalance surface m


Туре	SM480C
Light source	Philips Fortimo LED Line 1R
Power (+/-10%)	40 W (4000K / ACC-MLO)
Luminous flux	3000 or 3500 lm
Correlated color temperature	3000 or 4000 K
Color rendering index	≥80
Median useful life L90B50	25,000 hours at 25 °C
Median useful life L80B50	50,000 hours at 25 °C
Operating temperature range	+10 to +40°C
Driver	Built-in
Mains voltage	220-240 V / 50-60 Hz
Dimming	Dimmable
Controls system input	DALI
Options	Emergency lighting: 1.5 hours ActiLume Wireless
Material	Housing: polycarbonate and sheet meta Cover/optic: PMMA or polycarbonate
Color	White (WH) or silver grey (SI)
Optic	OLC micro-lens optic made of acrylic OLC micro-lens optic made of clear ac OLC micro-lens optic made of polycar
Connection	Push-in connector (PI)
Maintenance	Optical module sealed for life; no interna
Installation	Individual; locking the luminaire into pre ceiling plate (delivered with the luminai Through-wiring possible

Through-wiring possible Optional: use of surface mounted gea

Surface mounted SM480C













nounted	SmartBalance suspended
	SP480P (direct lighting version) SP482P (direct/indirect lighting version)
	Philips Fortimo LED Line 1R
	SP480P: 40 W (4000K / ACC-MLO) SP482P: 42 W (4000K / ACC-MLO)
	3000, 3500 or 4000 lm
	3000 or 4000 K
	≥80
	25,000 hours at 25 °C
	50,000 hours at 25 °C
	+10 to +40°C
	Built-in
	220-240 V / 50-60 Hz
	Dimmable
	DALI
	Coupling piece (to connect up to 3 luminaires) ActiLume Wireless
etal e	Housing: polycarbonate and sheet metal Cover/optic: PMMA or polycarbonate
	White (WH) or silver grey (SI)
ic (AC-MLO) acrylic (ACC-MLO) carbonate (PC-MLO)	OLC micro-lens optic made of acrylic (AC-MLO) OLC micro-lens optic made of clear acrylic (ACC-MLO) OLC micro-lens optic made of polycarbonate (PC-MLO)
	Push-in connector (PI)
nal cleaning required	Optical module sealed for life; no internal cleaning required
pre-mounted naire) ar tray adapter	Suspended mounting with a set of single steel-wire suspensions including a power cord, 170 cm Suspension set SM1: set with twin metal tubes Suspension set SM2: set with ceiling cap and metal tube Suspension set SMT1: connection with clips to an exposed T-bar ceiling with two steel-wire suspensions Fast fine adjustment with clutch device (Reutlinger) Through-wiring possible Optional: coupling piece for mechanical and power/data

Suspended SP482P direct/indirect lighting

connection of up to three suspended luminaires



SP482P W24L134 LED40S-840 ACC-MLO




### Specification




#### SmartBalance free floor standing


Туре	FS484F
Light source	Philips Fortimo LED Line 1R
Power (+/-10%)	106 W (LED118S version for standalone lighting applications, 4000 K) 40 W (LED45S version for supporting lighting applications, 4000 K)
Luminous flux	11,800 lm (LED118S, 4000 K) 4500 lm (LED45S, 4000 K)
Correlated color temperature	3000 or 4000 K
Color rendering index	≥80
Median useful life L90B50	25,000 hours at 25 °C
Median useful life L80B50	50,000 hours at 25 °C
Operating temperature range	+10 to +40 °C
Driver	Built-in
Mains voltage	220-240 V / 50-60 Hz
Dimming	Dimmable via touch button
Options	Dimming of direct and indirect light separately (SW) Swiss power plug (CCH)
Material	Head and pole: lacquered aluminum Base: lacquered steel
Color	White (WH) similar to RAL 9003 Other colors available on request
Optic	Micro-lens optic, clear acrylate (ACC-MLO)
Connection	Cable, length 250 cm, with plug CEE7 (CCE)
Maintenance	Optical module sealed for life; no internal cleaning required
Installation	Luminaire comes pre-wired with a mains plug



FS484F LED1185/840 MLO







### Choice sheet and ordering codes

Choice sheet for surface mounted and suspended

Туре	Lumen package	Color temperature	Driver	Control	S
SM480C	LED305 <sup>(1)</sup>	830	PSR	No	
SP480P	LED35S <sup>(1)</sup>	840	PSD	ACW-N	S <sup>(3)</sup>
SP482P	LED405 <sup>(2)</sup>		PSD-T		
Optics	Emergency lighting	Suspension set (7)	Color housing	Cable (7)	
PC-MLO (4)	No	No	WH	No	
AC-MLO (4)	EL1.5-LED (6)	SM1	SI	C1700-5	5-WH <sup>(8)</sup>
ACC-MLO <sup>(5)</sup>		SMT1		C1700-5	5P-SI <sup>(8) (9)</sup>
		SM2		C1700-3	3-WH <sup>(3)</sup>
				C1700-3	3P-SI <sup>(3) (9)</sup>
<ol> <li>Not for SP482P</li> <li>Not for SM480C / 5</li> <li>Not for driver types</li> </ol>		4 : Not for lumen package Ll 5 : Not for lumen package Ll 6 : Not for SP480P / SP482F		8 : Not fo	or SP480P / SP482P or ACW-NS or color housing WH
Product ID		European ordering code	Product ID		European
		of defining code			ordering cod
Surface mounted			Coupling piece for suspended		ordering cod
	30 PSD W24L134 AC-MLO F		Coupling piece for suspended SP480Z CP WH		26503000
SM480C LED30S/83	30 PSD W24L134 AC-MLO F 40 PSD W24L134 AC-MLO F	PI 27350900			
SM480C LED30S/83 SM480C LED30S/84		PI 27350900 PI 27349300	SP480Z CP WH		26503000
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8:	40 PSD W24L134 AC-MLO F	PI 27350900 PI 27349300 D PI 27352300	SP480Z CP WH SP480Z CP SI	ensor	26503000
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8: SM480C LED355/8:	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC	PI 27350900 PI 27349300 O PI 27352300 O PI 26756000	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless		26503000 26504700
SM480C LED305/8 SM480C LED305/8 SM480C LED355/8 SM480C LED355/8 SM480C LED355/8	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC	PI 27350900 PI 27349300 D PI 27352300 D PI 26756000 PI 27354700	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se		26503000 26504700 25061600
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8: SM480C LED355/8: SM480C LED305/8: SM480C LED305/8:	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC 30 PSD W24L134 PC-MLO F 40 PSD W24L134 PC-MLO F	PI 27350900 PI 27349300 D PI 27352300 D PI 26756000 PI 27354700	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se UID8410/10 Wireless Scene Remote	e HH	26503000 26504700 25061600
SM480C LED305/8 SM480C LED305/8 SM480C LED355/8 SM480C LED355/8 SM480C LED305/8 SM480C LED305/8 SM480C LED305/8 SM480C LED305/8	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC 30 PSD W24L134 PC-MLO F 40 PSD W24L134 PC-MLO F	PI     27350900       PI     27349300       PI     27352300       PI     26756000       PI     27354700       PI     27353000	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se UID8410/10 Wireless Scene Remote Free floor standing	2 HH /H	26503000 26504700 25061600 25669400
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8: SM480C LED305/8: SM480C LED305/8: SM480C LED305/8: SM480C LED305/8: Suspended direct lig	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC 30 PSD W24L134 PC-MLO F 40 PSD W24L134 PC-MLO F ghting	PI     27350900       PI     27349300       PI     27352300       PI     26756000       PI     27354700       PI     27353000	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se UID8410/10 Wireless Scene Remote Free floor standing FS484F LED45S/840 PSD-T MLO W	≥ HH ′H CL WH	26503000 26504700 25061600 25669400 27374500
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8: SM480C LED355/8: SM480C LED305/8: SM480C LED305/8: SM480C LED305/83 SP480P LED305/84	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC 30 PSD W24L134 PC-MLO F 40 PSD W24L134 PC-MLO F ghting 0 PSD W24L134 AC-MLO SI	PI     27350900       PI     27349300       PI     27352300       PI     26756000       PI     27354700       PI     27353000       PI     27354700       PI     27354700       PI     27354700	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se UID8410/10 Wireless Scene Remote Free floor standing FS484F LED45S/840 PSD-T MLO W FS484F LED45S/840 PSD-T MLO AC	2 HH 7H CL WH SW WH	26503000 26504700 25061600 25669400 27374500 27375200
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8: SM480C LED355/8: SM480C LED305/8: SM480C LED305/8: SM480C LED305/8: SP480P LED305/84: SP480P LED305/84:	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC 30 PSD W24L134 PC-MLO F 40 PSD W24L134 PC-MLO F ghting 0 PSD W24L134 AC-MLO SI 0 PSD W24L134 AC-MLO SI	PI     27350900       PI     27349300       PI     27352300       PI     26756000       PI     27354700       PI     27353000       PI     27354700       PI     27354700       PI     27354700	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se UID8410/10 Wireless Scene Remote Free floor standing FS484F LED45S/840 PSD-T MLO W FS484F LED45S/840 PSD-T MLO AC	HH H CLWH SWWH ACLWH	26503000 26504700 25061600 25669400 27374500 27375200 27376900
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8: SM480C LED355/8: SM480C LED305/8: SM480C LED305/8: SM480C LED305/84 SP480P LED305/84 SP480P LED305/84 SP480P LED305/84	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC 30 PSD W24L134 PC-MLO F 40 PSD W24L134 PC-MLO F ghting 0 PSD W24L134 AC-MLO SI 0 PSD W24L134 AC-MLO SI 0 PSD W24L134 AC-MLO SI	PI     27350900       PI     27349300       PI     27352300       O PI     26756000       PI     27354700       PI     27355400       M2     27355400       M2     27358500	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se UID8410/10 Wireless Scene Remote Free floor standing FS484F LED45S/840 PSD-T MLO W FS484F LED45S/840 PSD-T MLO AC FS484F LED118S/840 PSD-T MLO S	2 HH /H CL WH SW WH ACL WH	26503000 26504700 25669400 25669400 27374500 27375200 273776900 27377600
SM480C LED305/8: SM480C LED305/8: SM480C LED355/8: SM480C LED355/8: SM480C LED305/8: SM480C LED305/8: SM480C LED305/84 SP480P LED305/84 SP480P LED305/84 SP480P LED305/84	40 PSD W24L134 AC-MLO F 30 PSD W24L134 ACC-MLC 40 PSD W24L134 ACC-MLC 30 PSD W24L134 PC-MLO F 40 PSD W24L134 PC-MLO F 9 pSD W24L134 AC-MLO SI 0 PSD W24L134 AC-MLO SI 0 PSD W24L134 AC-MLO SI 0 PSD W24L134 AC-MLO SI 0 PSD ACC-MLO SM2 PI SI	PI       27350900         PI       27349300         PI       27352300         PI       26756000         PI       26756000         PI       27354700         PI       273554700         PI       27356100         M2       27355400         M2       27358500         26757700	SP480Z CP WH SP480Z CP SI Accessories for ActiLume Wireless LRM1770/10 OS Wireless Corner se UID8410/10 Wireless Scene Remote Free floor standing FS484F LED45S/840 PSD-T MLO W FS484F LED45S/840 PSD-T MLO AC FS484F LED118S/840 PSD-T MLO AC FS484F LED118S/840 PSD-T MLO AC	HH CLWH SWWH ACLWH CLWH	26503000 26504700 25061600 25669400 27374500 27375200 27377600 27377600

Product ID	European ordering code
Surface mounted	
SM480C LED30S/830 PSD W24L134 AC-MLO PI	27350900
SM480C LED30S/840 PSD W24L134 AC-MLO PI	27349300
SM480C LED35S/830 PSD W24L134 ACC-MLO PI	27352300
SM480C LED35S/840 PSD W24L134 ACC-MLO PI	26756000
SM480C LED30S/830 PSD W24L134 PC-MLO PI	27354700
SM480C LED30S/840 PSD W24L134 PC-MLO PI	27353000
Suspended direct lighting	
SP480P LED30S/830 PSD W24L134 AC-MLO SM2	27356100
SP480P LED30S/840 PSD W24L134 AC-MLO SM2	27355400
SP480P LED30S/840 PSD W24L134 AC-MLO SM2	27358500
SP480P LED35S/840 PSD ACC-MLO SM2 PI	26757700
SP480P LED30S/840 PSD PC-MLO SM2 PI SI	26710200
Suspended direct / indirect lighting	
SP482P LED40S/840 PSD W24L134 AC-MLO SM2	27359200
SP482P LED40S/830 PSD W24L134 AC-MLO SM2	27360800
SP482P LED40S/830 PSD ACC-MLO SM2 PI	27362200
SP482P LED40S/840 PSD ACC-MLO SM2 PI	26758400
SP482P LED405/830 PSD W24L134 PC-MLO SM2	27364600

SP482P LED40S/840 PSD W24L134 PC-MLO SM2 27363900

Visit the Philips Lighting website to find out more about the benefits of SmartBalance and the options to suit your requirements



All luminaires mentioned in the above overview have a white housing

Save an additional 30% energy with OccuSwitch Wireless, our smart sensor solution which is easy to install and offers maximum flexibility



For more information on Office Lighting visit www.philips.com/ledsinoffices



#### ©2014 Koninklijke Philips N.V.

All rights reserved. Reproduction in whole or in part is prohibited without the prior written consent of the copyright owner. The information presented in this document does not form part of any quotation or contract, is believed to be accurate and reliable and may be changed without notice. No liability will be accepted by the publisher for any consequence of its use. Publication thereof does not convey nor imply any license under patent – or other industrial or intellectual property rights. Document order number: SmartBalance#2 03/14